

Part List Per Kit

| Part | Part # | Description | Qty. |
|------|-----------------|--|------|
| A | 11-972DDFT-XXXX | Solid Plastic Flat Top DD" (Depth) x 72" | 1 |
| B | 40-3264320 | Screw #14 x 3/4" | 8 |

Recommended Tools: T27 Torx bit, Drill and Ø 3/16" drill bit, Clamps

Flat Tops can be added to the top for a finished look. Flat tops are 1/2" thick Solid Plastic and come in 72" lengths. The depth of the panel matches the depth of the locker.

- Locate flat top, place on top of locker (chamfered edges face up).
- Align the flat top panel with the front face of the locker.
- Pre-drill holes using a Ø 3/16" drill bit from the interior of the locker. Drill through the locker top (tops are 3/8" thick for traditional or 1/2" thick for traditional plus lockers). Drill into the underside of the flat top. **Do not drill through the flat top.**
- Fasten the flat top to the locker using the screws provided (B) from the interior of the locker
- The last flat top will be cut to length to finish the run. The cut edge should be turned to the interior of the run to prevent exposing the sharp edge.
- Use the predrilling methods described above when installing over fillers and blocking to secure flat top panel. Also shown in diagram below.

